



CENTRENOL

1. Feed the drop lead emerging from spigot of the Centrenol down the post.
 2. Insert the Centrenol spigot into the top of post so that the 2 threaded holes in the spigot align with the two machined holes near the top of the PASSAFE post.
 3. Tighten the two tri-head screws ensuring fibre washers are used.
 4. Fit the switch mode power supply on to the post base board with the screws supplied.
- Connect the drop lead to the 24v transformer output plug.

MODUCIC

1. Plug the connector emerging from the base of the MODUCIC into the corresponding connector at the top of the PASSAFE post.
2. Insert the MODUCIC spigot into the top of PASSAFE post so that the 2 threaded holes in the spigot align with the two holes near the top of the PASSAFE post
3. Tighten the two tri-head screws ensuring fibre washers are used.

Simmons signs Limited reserves the right to alter or improve this guide without prior notice.