



1. Using the supplied template as a guide drill the post as indicated with a 9.0Ø drill - (Ensure that the traffic flow is correctly aligned).
2. Feed the drop lead emerging from spigot of the Centrenol down the post.
3. Insert the Centrenol spigot into the top of post so that the 2 threaded holes in the spigot align with the two newly machined holes near the top of the post.
4. Tighten the two tri-head screws ensuring fibre washers are used.
5. Fit the 4 Amp Transformer on to the post base board with the screws supplied. Connect the drop lead to the 24v transformer output.

*Simmons signs Limited reserves the right to alter or improve this guide without prior notice.*