simmonsigns

EcoSafeLight Retrofit for Designplan Bergen Installation Guide



Luminaires not suitable for covering with thermally insulated material

Packaging

SAFETY FIRST

Isolate the mains electrical supply before commencing installation.

All electrical work must be carried out in accordance with the latest IET wiring regulations (BS7671) by suitably qualified engineers.

Nominal

Weight

Dimensions

WARNING: DO NOT STARE AT LEDs

Pack Contents







TOOLS REQUIRED

4-Hole security machine screwdriver

Pozidriv recess No. 4 screwdriver 3mm flat terminal screwdriver



All dimensions in mm

Simmonsigns Limited reserves the right to alter or improve this guide without prior notice.

simmonsigns.co.uk

+44 (0)7841 052 022 +44 (0)1952 293 333 sales@simmonsigns.co.uk Stafford Park 5 **Telford Shropshire** TF3 3AS

sımmonsigns

Method

Isolate power for safe working and removing existing light unit.

- Use the appropriate security tool to undo the six off front bezel M6 screws, taking care to support the front bezel whilst removing it. Front bezel fixing methods may vary.
- 2. With the front panel set aside you now have access to the existing light unit. Firstly remove the power connector plug then remove and retain the two fixings by hand that hold in the existing light unit. You will now be able to remove the light unit and dispose of it according to the WEEE directive.
- 3. Disconnect the mains wires from the existing connector block. Remove the power cable and connector block from the earth tang and fit the new connector block at the earth connection link. Wire in the Live, Neutral and Earth from the mains lead to the connector block (see wiring diagram). Next fit the conversion bracket over the two M5 studs and fix with two off M5 insulated washers and brass nuts. (See exploded view).

Wiring diagram



Lighting level adjustment

The switch position is factory set and should not be adjusted on site, this information is provided as a reference for potential future upgrades. Modifying the adjustment will affect the lighting levels prescribed in any lighting design provided.

The lighting level of this unit can be set using the rotary switch in the diagram below. Increments indicate the output level.

A 3mm flat terminal screwdriver may assist in turning this.



EcoSafeLight Retrofit for Designplan Bergen Installation Guide

4. Fit the Light Unit keyholes over the two screws in the conversion bracket and slide it to the left such that the screws are centred on the narrowest part of the keyholes and tighten the Pozidriv screws with the screwdriver.



- 5. Connect the LED panel plug to the dimming board connector (1) and then the LED panel to the moulded bracket by inserting the hooks (2) and push the panel to engage the clips (3).
- 6. The assembly instruction label should be fixed to the inside face of the Bergen body below the unit for future reference.
- 7. Finally lift and reposition the front bezel and fix into place with the retained six off M8 screws.

Disconnecting LED array

To disconnect the LED array from the moulded bracket, simply apply a gentle squeezing force with thumb and index finger on each of the two clip heads shown (1) and pull forward. When released slide the LED panel to the right to disengage the two hooks shown (2) and disconnect the LED panel plug (3).



Simmonsigns Limited reserves the right to alter or improve this guide without prior notice.

simmonsigns.co.uk

+44 (0)7841 052 022 +44 (0)1952 293 333 sales@simmonsigns.co.uk Stafford Park 5 Telford Shropshire TF3 3AS