



Tools Required.

- 1 x Tri head key
- 1 x 19mm long reach socket & ratchet
- 2 x 13mm A/F combination spanners

Installing a Weebol-Global adapter onto a Global.

Safety First - ensure the power supply is isolated before commencing work.

- 1) Unfasten the tri head fixing, located at the rear of the Global hinge frame, using the tri head key.
- 2) Open the Global hinge frame & remove the bollard - if installed.
- 3) Remove the clear, domed plastic lens from the Global.
- 4) Lift the exposed geartray from the Global, disconnect the power lead & remove.
- 5) Take the Weebol-Global adapter assembly & connect earth in accordance with IEE Wiring Regulations 17th Edition (BS 7671:2008).
- 6) Locate the Weebol-Global adapter assembly onto the Global base ensuring correct orientation i.e. front to front & engage the anti-rotational notch.
- 7) Close the Global hinge frame & securely fasten the tri head fixing.

Installing a Weebol onto a Weebol-Global adapter.

- 1) Remove the 4 M12 Nyloc nuts & Form C washers from the Weebol-Global adapter assembly & keep in a safe place.
- 2) Locate the Weebol knuckle into the Weebol lower plinth (ensuring correct orientation) & securely fix in position using the 4 M12 Nyloc nuts and washers.
- 3) Engage the 2 parts of the rebate cover together & place over the Weebol fixings / lower plinth. Ensure that the split line is aligned with the embossed "FRONT" on the Weebol adapter.

Simmons signs Limited reserves the right to alter or improve this guide without prior notice.