# sımmonsigns

### **Tools required**

2 - 13mm A/F combination spanners 19mm A/F combination spanner Tri head key Fixing kit required : WBLF/CONV or WBLF/CONV/GLV


#### Installation

- 1. Secure the Weebol Flex to the Adapter frame as Fig 2 - ensuring that white plastic spacers have been fitted into the mounting holes and that the orientation of the bollard is correct.
- 2. Loosen the trihead fixing and open the hinge frame.
- 3. Remove the existing bollard and retain the lens.
- 4. Disconnect the light unit safely.
- 5. Dispose of the bollard and light unit in the correct manner or retain for your convenience.
- 6. Replace the lens to ensure the base is sealed from water and debris ingress.
- 7. Secure the Weebol Flex and Adapter frame assembly to the hinge frame ensure correct orientation and the inner holes are used to secure the adapter to the hinge frame.
- 8. Close and secure the hinge frame.

## Weebol Flex Adapter/ Conversion Frame

Installation Guide

**Safety First -** Isolate electrical supply prior to commencing work.



Simmonsigns Limited reserves the right to alter or improve this guide without prior notice.

#### simmonsigns.co.uk

+44 (0)7841 052 022 +44 (0)1952 293 333 sales@simmonsigns.co.uk Stafford Park 5 Telford Shropshire TF3 3AS